ArtForm Diana Floor Plan Changes

- 1. Include bulkhead access to cellar in the center of the rear of house
- 2. Replace garage window with 36" door, swings in
- 3. Remove laundry and use that space to expand master closet
 - a. Change master closet to 24" pocket door located in center of bedroom wall
- 4. Make attic access pull-down stairs located inside of master closet centered on pocket door
- 5. In spare bedroom, remove small/upper left-side window
- 6. In main bath, add 24" x 16" crank-out awning window as high up on wall as possible
- 7. Extend right wall of house/garage out 2', so that total house width is 34'
 - a. In master bedroom, replace single small/upper right-side window with two 16" double-hung windows that have 8' of wall space between the two windows
 - b. Remove tub/shower from <u>master bath</u>
 - i. Use ½ of that space for linen closet on the inside of main bath
 - ii. Use the other ½ of that tub/shower space for raceway to run 6" metalbestos chimney up to roof from cellar
 - iii. Change master bath to pocket door
 - c. Extend width of vanity in main bath proportionally
- 8. Combine original linen and hall closets into one larger hall closet with folding doors
- 9. Include plumbing hookups and dryer vent for laundry in cellar below bathrooms
- 10. Remove outdoor deck and kitchen island

Questions:

- 1. 2x4 or 2x6 construction?
- 2. With house width change, what is the pitch on the roof?
- 3. Where is the furnace vent/chimney located?
- 4. What is width of main and master bath doors?
- 5. Where does the fan/vent for the main bath exit?
- 6. How deep are the front/rear eves?
- 7. Do bedroom windows on rear of house meet NH egress code requirements?

Richard Noël

H: 603.887.3263 M: 603.365.0659